Blinder®400 QUICKSTART GUIDE

WHAT'S IN THE PACK

OPERATION

⚠ *NOTE THE BLINDER 400 IS PACKAGED IN DEMO MODE. TO ENABLE FULL FUNCTION OF THE LIGHT, CONNECT IT TO A USB-C CHARGER.*

LONG PRESS (2 SECS): ON/OFF
QUICK PRESS: CHANGE MODE
DOUBLE PRESS: TOGGLE BETWEEN STEADY & FLASH MODES

QUICK PRESS WHEN OFF TO CHECK BATTERY STATUS

CHARGING

LIFT THE CHARGING-PORT HATCH.

INSERT USB TYPE-C CHARGING CABLE.

ONCE THE CHARGE CABLE IS INSERTED, THE POWER BUTTON WILL GLOW AMBER INDICATING THE LIGHT IS NOW IN CHARGING MODE.

ONCE FULLY CHARGED, THE POWER BUTTON WILL GLOW GREEN. AFTER 1 MINUTE THE GREEN LIGHT WILL TURN OFF.

BATTERY STATUS

A QUICK PRESS OF THE POWER BUTTON WILL INDICATE THE

⚠ *WHEN THE POWER BUTTON LIGHT IS FLASHING RED, THE LIGHT'S OUTPUT WILL BE REDUCED TO 30% TO PRESERVE RUNTIME.*

MOUNTING

SELECT THE CORRESPONDING HOLE TO SUIT YOUR BAR DIAMETER.

FIRMLY HOLD THE MOUNT IN PLACE & STRETCH THE STRAP DIAGONALLY.

THEN PULL THE STRAP AROUND THE BAR & SECURE ON THE HOOK.

PLACE THE LIGHT ON THE CRADLE.

COMPLETE MOUNTING BY PULLING UP ON THE TAB WHILE APPLYING DOWNWARD PRESSURE TO CLICK THE LIGHT INTO POSITION.

MAKE SURE THE LIGHT IS SECURE BEFORE RIDING!

TO REMOVE, PRESS DOWN ON TAB & GENTLY PULL LIGHT AWAY FROM CRADLE.

UNDER MOUNT (SOLD SEPERATELY)

LOCKED UN-LOCKED

PLACE THE LIGHT INSIDE THE MOUNT IN THE UN-LOCKED POSITION.

LOCK THE UNDER-MOUNT.

⚠ ***MAKE SURE THE UNDER-MOUNT IS LOCKED BEFORE RIDING. DO NOT RIDE WITH THE UNDER-MOUNT UNLOCKED!*

REFER TO YOUR GO-PRO OR COMPUTER MOUNT INSTRUCTIONS TO COMPLETE BLINDER UNDER-MOUNT INSTALLATION.

MODES & RUNTIMES

Blinder®400		
MODE	LUMENS	RUNTIME
HIGH	400	2.5HR
MEDIUM	200	5HR
LOW	100	9HR
PULSE	150	9HR
STROBE	150	15HR
ECO	100	100HR

TECHNICALLY
UNCONVENTIONAL

DESIGNED IN MARIN [MELBOURNE] BY KNOG ©
2 YEAR WARRANTY-DETAILS AT KNOG.COM