

# Blinder® Link

## QUICKSTART GUIDE



### WHAT'S IN THE BOX



### OPERATION



POWER BUTTON


LONG PRESS - ON/OFF

STANDARD PRESS - CYCLES THROUGH ALL 8 MODES

### MOUNTING



REMOVE THE LIGHT FROM THE MOUNT




LOOSEN THE BOLT TO OPEN THE CLAMP



INSERT THE MOUNT BETWEEN THE SADDLE RAILS AT THE WIDEST POINT, THEN LOWER THE MOUNT INTO THE DESIRED POSITION



ONCE IN POSITION, TIGHTEN THE BOLT



SLIDE THE LIGHT BACK ONTO THE MOUNT



ADJUST THE LIGHT TO THE DESIRED ANGLE & TIGHTEN THE BOLT

### WEARABLE



THE INTEGRATED CLIP-MOUNT TURNS THE BLINDER LINK INTO A WEARABLE LIGHT



- THE CLIP-MOUNT IS DESIGNED TO MOUNT TO THICK MATERIALS AND STRAPS
- MAKE SURE THE LIGHT IS MOUNTED VERTICALLY WITH THE POWER BUTTON AT THE TOP
- BEFORE WEARING THE LIGHT, MAKE SURE THE LIGHT IS TIGHTLY FITTED AND SECURE BEFORE USE

### BATTERY STATUS




WHEN THE BATTERY IS RUNNING LOW, THE RED LED WILL APPEAR


### CHARGING



CAREFULLY OPEN CHARGING-PORT HATCH



INSERT USB C CHARGING CABLE  
RED LED INDICATES CHARGING



GREEN LED INDICATES FULLY CHARGED

### MODES & RUNTIMES

MODE	LUMENS	RUNTIME
Steady High	35	4hr
Steady Low	20	7hr
High Flash	100	7hr
Low Flash	50	19hr
Fading Flash	30	14hr
Pulse Flash	70	19hr
Accelerating Flash	30	7hr
Eco Flash	30	100hr



TECHNICALLY  
UN@NVENTIONAL

DESIGNED IN NAARM [MELBOURNE] BY KNOG ©  
2 YEAR WARRANTY-DETAILS AT KNOG.COM