

Blinder[®]R-150

QUICKSTART GUIDE



OPERATION

POWER BUTTON



LONG PRESS - ON/OFF

QUICK PRESS - CYCLES THROUGH ALL 8 MODES

CHARGING



RECHARGE BEFORE FIRST USE

THE R-150 REQUIRES 3HRS TO BE FULLY CHARGED

WHEN PLUGGED IN TO CHARGE, RED LED INDICATES THE R-150 IS CHARGING




GREEN LED INDICATES FULLY CHARGED



LOW BATTERY

WHEN IN USE, THE RED LED WILL APPEAR WHEN THE BATTERY IS BELOW 10%



MOUNTING

MEASURE YOUR SEAT POST USING CALOIPERS OR A SOFT MEASURING TAPE

SELECT THE CORRECT SIZE STRAP

(THE PACK INCLUDES SMALL, MEDIUM AND LARGE STRAPS)



Ø 22-27MM



Ø 27-32MM



Ø 32+MM

(SUITABLE FOR AERO POSTS)



PULL STRAP AROUND SEAT POST AND LATCH ON

MODES & RUNTIMES

MODE	LUMENS	RUNTIME
High	35	3.5hr
Peloton	2	30hr
Strobe	150	7.5hr
Impact	110	25hr
Beacon	85	6.5hr
Wave	90	4.5hr
Bounce	100	6.5hr
Burn	130	2.5hr
Eco	8	50hr

TECHNICALLY
UNCONVENTIONAL

DESIGNED IN NAARM [MELBOURNE] BY KNOG ©
2 YEAR WARRANTY-DETAILS AT KNOG.COM