# Blinder®1300 QUICKSTART GUIDE

Blinder 1300 is precise, powerful, long-lasting and the perfect choice for road and gravel cyclists who demand the very best performance from their equipment. Featuring robust CNC construction, compact design, perfect beam angles, an incredible weight-to-power ratio and multiple mounting options, Blinder 1300 front bike light makes the ride by which Front bike lights are measured.

## WHAT'S IN THE PACK

## OPERATION

NOTE: THE BLINDER 1300 IS PACKAGED IN SHIPPING MODE. TO ENABLE FULL FUNCTION OF THE LIGHT, CONNECT IT TO A USB-C CHARGER.

POWER BUTTON

LONG PRESS (2 SECS): ON/OFF
QUICK PRESS: CHANGE MODE
DOUBLE PRESS: TOGGLE BETWEEN STEADY & FLASH MODES

QUICK PRESS WHEN OFF TO CHECK BATTERY STATUS

## CHARGING

LIFT THE CHARGING-PORT HATCH.

INSERT USB TYPE-C CHARGING CABLE.

ONCE THE CHARGE CABLE IS INSERTED, THE POWER BUTTON WILL GLOW AMBER INDICATING THE LIGHT IS NOW IN CHARGING MODE.

ONCE FULLY CHARGED, THE POWER BUTTON WILL GLOW GREEN. AFTER 1 MINUTE THE GREEN LIGHT WILL TURN OFF.

## BATTERY STATUS

ONCE FULLY CHARGED, THE POWER BUTTON WILL GLOW GREEN. AFTER 1 MINUTE THE GREEN LIGHT WILL TURN OFF.

⚠ WHEN THE POWER BUTTON LIGHT IS FLASHING RED THE LIGHT'S OUTPUT WILL BE REDUCED TO 20% TO PRESERVE RUNTIME.

## MOUNTING

BAR MOUNT

SELECT THE CORRESPONDING HOLE TO SUIT YOUR BAR DIAMETER.

FIRMLY HOLD THE MOUNT IN PLACE & STRETCH THE STRAP DOWNWARDS.

THEN PULL THE STRAP AROUND THE BAR & SECURE ON THE HOOK.

PLACE THE LIGHT IN THE CRADLE.

COMPLETE MOUNTING BY PULLING UP ON THE TAB WHILE APPLYING DOWNWARD PRESSURE TO CLICK THE LIGHT INTO POSITION.

MAKE SURE THE LIGHT IS SECURE BEFORE RIDING!

TO REMOVE, PRESS DOWN ON TAB & GENTLY PULL LIGHT AWAY FROM CRADLE.

UNDER MOUNT

PLACE THE LIGHT INSIDE THE MOUNT IN THE UN-LOCKED POSITION.



LOCK THE UNDER-MOUNT.

⚠ MAKE SURE THE UNDER-MOUNT IS LOCKED BEFORE RIDING. DO NOT RIDE WITH THE UNDER-MOUNT UNLOCKED!

REFER TO YOUR GO-PRO OR COMPUTER MOUNT INSTRUCTIONS TO COMPLETE BLINDER UNDER-MOUNT INSTALLATION.

## MODES & RUNTIMES

| Blinder®1300 | | |
|---|---|---|
| MODE | LUMENS | RUNTIME |
| HIGH | 1300 | 1.5HR |
| MEDIUM | 650 | 3HR |
| LOW | 230 | 8HR |
| PULSE | 420 | 8HR |
| STROBE | 230 | 16HR |
| ECO | 150 | 120HR |

TECHNICALLY UNSONVENTIONAL

DESIGNED IN MAHKN (MELBOURNE) BY KNOG ©
2 YEAR WARRANTY-DETAILS AT KNOG.COM