

Blinder®

QUICKSTART GUIDE




CHARGING



Please recharge before first use!!


USB PLUG



WALL PLUG



INTERFACE




1. LOW BATTERY INDICATOR
2. POWER / MODE SWITCH
3. RECHARGE INDICATOR

LONG PRESS 2 TO TURN LIGHT ON/OFF

SHORT PRESS 2 TO CYCLE MODES

FITMENT

3 STRAP SIZES INCLUDED




BLINDERS COME PRE-FITTED TO CLASP WITH MEDIUM STRAP


INTERCHANGEABLE STRAP



STRETCH STRAP TO FIT CLASP




PLACE STRAP END OVER HOOK



PULL STRAP TOWARD THE LIGHT BODY

MOUNTING



1. PULL SILICONE STRAP AROUND BAR
2. ENGAGE LATCH INTO HOOK

THE RANGE



TECHNICALLY
UN®ONVENTIONAL

DESIGNED IN NAARM [MELBOURNE] BY KNOG ®
2 YEAR WARRANTY-DETAILS AT KNOG.COM